DIGIPLEX

DIGIPLEX NE

Voice-Assisted Arm/Disarm Module

User's Manual

PARADOX®
SECURITY SYSTEMS

APR3ADM2-EU01
Printed in Canada - 11/2001
www.paradox.ca

TABLE OF CONTENTS

INTRODUCTION 4

ACCESS CODES 4

HOW DO I USE IT? 4

THINGS YOU SHOULD KNOW..... 6

When Accessing your APR3-ADM2... 6

When Arming or Disarming... 6

When Activating or Deactivating an Output... 6

When Using your APR3-ADM2... 7

TELEPHONE PUSH BUTTON FEATURES 7

Clear - [*]..... 7

Activate/Deactivate APR3-ADM2 Output - [#] [0]..... 7

Hang Up - [#] [9]..... 8

SYSTEM CHECKLIST 8

APR3-ADM2 EXAMPLE..... 9

INTRODUCTION

Congratulations for choosing the Paradox Security System Voice-Assisted Arm/Disarm Module. The APR3-ADM2 turns any touch-tone telephone into a keypad. With the APR3-ADM2, you can now arm or disarm your Digiplex or DigiplexNE security system as well as activate or deactivate your APR3-ADM2's output all from your telephone. Using detailed voice prompts to guide your way, the APR3-ADM2 is as simple as picking up your telephone.

ACCESS CODES

The APR3-ADM2 uses your Digiplex or DigiplexNE User Access code to grant you access to your Digiplex or DigiplexNE Security System. The User Access Code you would enter into your Digiplex or DigiplexNE system keypad is the same User Access Code you will use to enter on your telephone.

HOW DO I USE IT?

STEP 1: Pick up your telephone and dial your telephone number (the telephone number of the line that your APR3-ADM2 is connected to).

The APR3-ADM2 will now ask you to enter your Digiplex or DigiplexNE User Access Code.

STEP 2: Enter your Digiplex or DigiplexNE User Access Code.

If your Digiplex or DigiplexNE Security System is programmed to accept variable code lengths, you must press the [#] key after entering your access code.

STEP 3: Keys **[1]** to **[8]** on your telephone represent areas 1 to 8 just like your keypad. To arm or disarm your Digiplex or DigiplexNE security system, press the desired area's number on your telephone. This will toggle the area's arming state from armed to disarmed and vice versa. Refer to Example 1 on page 9.

Areas 5 to 8 are only accessible if connected to a DigiplexNE Security System.

STEP 4: To activate or deactivate the APR3-ADM2's output, press the **[#]** key and then the **[0]** key. Refer to Example 1 on page 9.

When Accessing your APR3-ADM2...

- If you are using an answering machine or service, call the APR3-ADM2, hang-up, wait 10 seconds and then call the APR3-ADM2 back to access it.

When Arming or Disarming...

- You will only be able to arm or disarm areas that your User code has access to.
- If you were to arm an area with an open zone, Digiplex or DigiplexNE will *Force Arm* the area. This will only happen with User access codes that have the *Force Arming* feature enabled.

When Activating or Deactivating an Output...

- Your APR3-ADM2's output can be used to turn on lights, open or close a garage door and much more. Ask your installer about this useful feature.
- If the APR3-ADM2's output is not operational, you will not be able to activate or deactivate the output.
- Your installer can program the output to either deactivate manually or follow a timer. If programmed to be deactivated manually, the output will remain activated

until you deactivate it. If programmed to follow a timer, the output will deactivate after the timer has elapsed.

When Using your APR3-ADM2...

- In some cases, your telephone's tone may not be powerful enough to interrupt the APR3-ADM2's voice prompt. If this is the case, simply wait for the APR3-ADM2's voice prompt to finish before entering your action.
- If your Digiplex or DigiplexNE security system and APR3-ADM2 share the same telephone number, you may be interrupted at times when using your APR3-ADM2.

TELEPHONE PUSH BUTTON FEATURES

Clear - [*]

If you have made an error, press the **[*]** key on your telephone to clear the error and then re-enter the information.

Activate/Deactivate APR3-ADM2 Output - [#] [0]

To activate or deactivate the APR3-ADM2's output, press the **[#]** key and then the **[0]** key from your telephone.

Hang Up - [#] [9]

When you wish to hang up, press the **[#]** key and then the **[9]** key to immediately hang up. The APR3-ADM2 will confirm the hang up with *"Good-bye"*.

If the Hang Up feature is not used and if no action is performed after two minutes, the APR3-ADM2 will hang up automatically.

SYSTEM CHECKLIST

Telephone Number: _____

Output Activates: _____

Output follows: ◩ 1 Output Timer
◩ 2 Manual Deactivation

Output Timer Length: _____ ◩ 3 sec. or ◩ 4 min.

Call, hang-up, and then call back within ____ sec.

# of rings before the APR3-ADM2 answers: ____

Area Assignment: ◩ 1 ◩ 2 ◩ 3 ◩ 4

(DigiplexNE only) → ◩ 5 ◩ 6 ◩ 7 ◩ 8

Your User Access Code must also have access to the areas (partitions) to which the APR3-ADM2 is assigned to.

APR3-ADM2 EXAMPLE

Example 1: Using the APR3-ADM2

Nelson has a Digiplex security system and an APR3-ADM2 hooked up at home. His security system has two areas. Both areas are presently armed and the APR3-ADM2's output (which is hooked up to his garage door opener) is deactivated. Nelson is on his way home and wishes to disarm both areas and open his garage door. Nelson performs the following:

Nelson first dials the telephone number of the line to which the APR3-ADM2 is connected to.

When the APR3-ADM2 picks up, it will prompt Nelson with the following:

"Please enter your code."

Nelson enters his User Access Code.

The APR3-ADM2 then prompts Nelson with the following:

"Area 1 Armed"
"Area 2 Armed"
"Output is Deactivated"
"To modify, enter Area number"

Nelson presses the **[1]** key on his telephone to disarm Area 1.

The APR3-ADM2 then prompts Nelson with the following:

"Area 1 Disarmed"
"Area 2 Armed"
"Output is Deactivated"
"To modify, enter Area number"

Nelson presses the **[2]** key on his telephone to disarm Area 2.

The APR3-ADM2 then prompts Nelson with the following:

"Area 1 Disarmed"
"Area 2 Disarmed"
"Output is Deactivated"
"To modify, enter Area number"

Nelson then presses the **[#]** key and then the **[0]** key on his telephone to activate the output which in turn will activate the garage door.

The APR3-ADM2 then prompts Nelson with the following:

“Output is Activated”

SPECTRA™

Voice-Assisted Arm/Disarm Module

User's Manual

PARADOX®
SECURITY SYSTEMS

APR3ADM2-EU01
Printed in Canada - 11/2001
www.paradox.ca

TABLE OF CONTENTS

INTRODUCTION 4

ACCESS CODES 4

Stand-alone Code (default 123456)..... 4

User Access Codes 5

HOW DO I USE IT? 5

THINGS YOU SHOULD KNOW..... 6

When Accessing your APR3-ADM2... 6

When Arming or Disarming... 6

When Activating or Deactivating an Output... 7

When Entering Your Stand-alone Code... 8

When Using your APR3-ADM2... 8

TELEPHONE PUSH BUTTON FEATURES 8

Clear - [*]..... 8

Change Stand-alone Code - [#] [8]..... 9

Activate/Deactivate APR3-ADM2 Output - [#] [0]..... 9

Hang Up - [#] [9]..... 9

SYSTEM CHECKLIST 9

APR3-ADM2 EXAMPLE..... 10

INTRODUCTION

Congratulations for choosing the Paradox Security System Voice-Assisted Arm/Disarm Module. The APR3-ADM2 turns any touch-tone telephone into a keypad. With the APR3-ADM2, you can now arm or disarm your Spectra security system as well as activate or deactivate your APR3-ADM2's output all from your telephone. Using detailed voice prompts to guide your way, the APR3-ADM2 is as simple as picking up your telephone.

ACCESS CODES

The APR3-ADM2 uses two types of access codes to allow access to your Spectra Security System, the stand-alone code and the User's Access codes.

Stand-alone Code (default 123456)

The stand-alone code is the code that logs you on to the APR3-ADM2. This code does not give you access to your Spectra Security System. To do so, you must then enter your User Access Code. Ask your installer whether your stand-alone code is 4-digits or 6-digits in length.

User Access Codes

The APR3-ADM2 uses your Spectra User's Access code to grant you access to your Spectra Security System. The Spectra User Access Code you would enter into your Spectra system keypad is the same User Access Code you will use to enter on your telephone.

HOW DO I USE IT?

STEP 1: Pick up your telephone and dial your telephone number (the telephone number of the line that your APR3-ADM2 is connected to).
The APR3-ADM2 will now ask you to enter your stand-alone Code.

STEP 2: Enter your stand-alone code (default **123456**).

STEP 3: After the voice prompt, enter your Spectra User Access Code.

STEP 4: If your Spectra has not been partitioned, proceed to STEP 5. If your Spectra has been partitioned, keys **[1]** and **[2]** from your telephone represent partitions 1 and 2 just like your keypad. To arm or disarm your Spectra security system, press the desired partitions's number on your

telephone. This will toggle the partition's arming state from armed to disarmed and vice versa. Refer to Example 1 on page 10.

STEP 5: To activate or deactivate the APR3-ADM2's output, press the **[#]** key and then the **[0]** key. Refer to Example 1 on page 10.

STEP 6: To change your stand-alone code, press the **[#]** key and then the **[8]** key. After the voice prompt, enter your new stand-alone code. Then enter the same code again so that the APR3-ADM2 can verify your new code.
The APR3-ADM2 will confirm the new stand-alone code with a "Code Changed" prompt.

THINGS YOU SHOULD KNOW

When Accessing your APR3-ADM2...

- If you are using an answering machine or service, call the APR3-ADM2, hang-up, wait 10 seconds and then call the APR3-ADM2 back to access it.

When Arming or Disarming...

- You will only be able to arm or disarm

areas that your User code has access to.

- If your Spectra Security System is partitioned, once you have performed an action to a partition, you will not be able to perform another action to the same partition until you exit and re-enter your User Access Code.
- If your Spectra has not been partitioned, once you enter your User Access Code, the arming state of the Spectra will automatically be changed and no partition options will be prompted.
- If your Spectra has been partitioned, but your User Access Code only has access to one partition, when you enter your User Access Code, the APR3-ADM2 will automatically change the arming state of the partition you have access to.

When Activating or Deactivating an Output...

- Your APR3-ADM2's output can be used to turn on lights, open or close a garage door and much more. Ask your installer about this useful feature.
- If the APR3-ADM2's output is not operational, you will not be able to activate or deactivate the output.
- Your installer can program the output to either deactivate manually or follow a timer.

If programmed to be deactivated manually, the output will remain activated until you deactivate it. If programmed to follow a timer, the output will deactivate after the timer has elapsed.

When Entering Your Stand-alone Code...

- If the stand-alone code is entered incorrectly after 3 consecutive attempts, the APR3-ADM2 will immediately hang up.

When Using your APR3-ADM2...

- In some cases, your telephone's tone may not be powerful enough to interrupt the APR3-ADM2's voice prompt. If this is the case, simply wait for the APR3-ADM2's voice prompt to finish before entering your action.
- If your Spectra security system and APR3-ADM2 share the same telephone number, you may be interrupted at times when using your APR3-ADM2.

TELEPHONE PUSH BUTTON FEATURES

Clear - [*]

If you have made an error, press the **[*]** key on your telephone to clear the error and then re-enter the information.

Change Stand-alone Code - [#] [8]

To change the stand-alone code (default **123456**), press the **[#]** key and then press the **[8]** key from your telephone. After the voice prompt, enter your new stand-alone code. Then enter the same code again so that the InTouch can verify your new code.

Activate/Deactivate APR3-ADM2 Output - [#] [0]

To activate or deactivate the APR3-ADM2's output, press the **[#]** key and then the **[0]** key from your telephone.

Hang Up - [#] [9]

When you wish to hang up, press the **[#]** key and then the **[9]** key to immediately hang up. The APR3-ADM2 will confirm the hang up with *"Good-bye"*.

If the Hang Up feature is not used and if no action is performed after 2 minutes, the APR3-ADM2 will hang up automatically.

SYSTEM CHECKLIST

Telephone Number: _____

Stand-alone Code: ◩ ◪6-digits ◩ ◪4-digits

Output Activates: _____

Output follows: ◩ ◪Output Timer
◩ ◪Manual Deactivation
Output Timer Length: _____ ◩ ◪sec. or ◩ ◪min.

Call, hang-up, and then call back within ____ secs.

# of rings before the APR3-ADM2 answers: _____

An area and a partition are two words to describe the same thing. Your Spectra's partitions are called areas by the APR3-ADM2.

APR3-ADM2 EXAMPLE

Example 1: Using the APR3-ADM2

Nelson has a Spectra security system and an APR3-ADM2 hooked up at home. His security system has two partitions. Both partitions are presently armed and the APR3-ADM2's output (which is hooked up to his garage door opener) is deactivated. Nelson is on his way home and wishes to disarm both partitions and open his garage door. Nelson performs the following:

Nelson first dials the telephone number of the line to which the APR3-ADM2 is connected to.

When the APR3-ADM2 picks up, it will prompt Nelson with the following:

"Enter your Stand-alone code."

Nelson enters his Stand-alone Code.

The APR3-ADM2 then prompts Nelson with the following:

"Area 1 Armed"
"Area 2 Armed"
"Output is Deactivated"
"Please enter your code."

Nelson enters his User Access Code.

The APR3-ADM2 then prompts Nelson with the following:

"Area 1 Armed"
"Area 2 Armed"
"Output is Deactivated"
"To change, enter Area number 1"
"Area number 2"

Nelson presses the **[1]** key on his telephone to disarm partition 1.

The APR3-ADM2 then prompts Nelson with the following:

"Area 1 Disarmed"
"Area 2 Armed"
"Output is Deactivated"
"To change, enter Area number 2"

Nelson presses the **[2]** key on his telephone to disarm partition 2.

The APR3-ADM2 then prompts Nelson with the following:

"Area 1 Disarmed"
"Area 2 Disarmed"
"Output is Deactivated"
"Please enter your code"

Nelson then presses the **[#]** key and then the **[0]** key on his telephone to activate the output which in turn will activate the garage door.

The APR3-ADM2 then prompts Nelson with the following:

"Output is Activated"